
MODEL: R3-AV8

Remote I/O R3 Series

DC VOLTAGE INPUT ALARM MODULE

(8 points, isolated)



MODEL: R3-AV8[1][2]

ORDERING INFORMATION

• Code number: R3-AV8[1][2]

Specify a code from below for each [1] and [2].

(e.g. R3-AV8W/CE/Q)

• Specify the specification for option code /Q

(e.g. /C01)

NO. OF CHANNELS

8: 8

[1] COMMUNICATION MODE

S: Single **W**: Dual

[2] OPTIONS (multiple selections)

Standards & Approvals

blank: Without CE /CE: CE marking Other Options blank: none

/Q: Option other than the above (specify the specification)

SPECIFICATIONS OF OPTION: Q

COATING (For the detail, refer to M-System's web site.)

/C01: Silicone coating /C02: Polyurethane coating /C03: Rubber coating

CAUTION

■UNUSED INPUT CHANNELS

Set the unused input channels to ±10 V range. Unused

channels left open with other settings may be equal to the input lower than -15 %, which sets a data abnormality at the PLC or the host device.

Open circuit with the input range set to ± 10 V means 50 % of the full-scale. An alarm setpoint must be set to a value that does not trip an unwanted alarm.

Unused channels can be specified and set so on the PC Configurator Software (model: R3CON) without needing the above mentioned setting.

GENERAL SPECIFICATIONS

Connection

Internal bus: Via the Installation Base (model: R3-BSx) Input: M3 separable screw terminal (torque 0.5 N·m) Internal power: Via the Installation Base (model: R3-BSx)

Screw terminal: Nickel-plated steel

Isolation: Input 1 to input 2 to input 3 to input 4 to input 5 to input 6 to input 7 to input 8 to internal bus or internal power

Input range: Selectable with the side DIP SW (per 4

channels

Conversion rate: Selectable with the side DIP SW

RUN indicator: Bi-color (red/green) LED; Red when the bus A operates normally; Green when the bus B operates normally; Amber when both buses operate normally. ERR indicator: Bi-color (red/green) LED; Red with the input circuit abnormality (AD

converter response failure);

Green in normal operating conditions.

INPUT SPECIFICATIONS

■ Narrow Span: -1 - +1 V, 0 - 1 V DC

Input resistance: $100 \text{ k}\Omega \text{ min.}$

■ Wide Span: -10 - +10 V, -5 - +5 V,

0 - 10 V, 0 - 5 V, 1 - 5 V DCInput resistance: $1 \text{ M}\Omega \text{ min}$.

INSTALLATION

Operating temperature: -10 to +55°C (14 to 131°F)
Operating humidity: 30 to 90 %RH (non-condensing)

Atmosphere: No corrosive gas or heavy dust **Mounting**: Installation Base (model: R3-BSx)

Weight: 250 g (0.55 lb)

PERFORMANCE

Conversion accuracy: Refer to the table at the end of this

Website: www.xintop.com

section.

FAX: (02)2596-2331

Conversion rate: 160 / 80 / 40 / 20 msec. selectable

TEL: (02)2598-1199 E-mail: info@xintop.com

Data range: 0 - 10000 of the input range

Data allocation: 4



MODEL: R3-AV8

TEL: (02)2598-1199 E-mail: info@xintop.com FAX: (02)2596-2331 Website: www.xintop.com

Current consumption: 100 mA

Temp. coefficient: ±0.015 % /°C (±0.008 %/°F)

(±0.03 % /°C [±0.02 %/°F] with 0 - 5 V or 1 - 5 V range)

Insulation resistance: \geq 100 M Ω with 500 V DC

Dielectric strength: 1000 V AC @ 1 minute (input 1 to input 2 to input 3 to input 4 to input 5 to input 6 to input 7 to

input 8 to internal bus or internal power)

2000 V AC @ 1 minute (power input to FG; isolated on the

power supply module)

Conversion accuracy

RANGE RATE	160 msec.	80 msec.	40 msec.	20 msec.
All ranges	±0.1%	±0.2%	±0.4%	±0.8%

STANDARDS & APPROVALS

CE conformity:

EMC Directive (2004/108/EC) EMI EN 61000-6-4: 2007/A1: 2011

EMS EN 61000-6-2: 2005

ALARM SETTING

The following parameters are programmable using the PC Configurator Software (model: R3CON).

■ALARM TRIP POINT (-15.00 to +115.00 %)

Four alarm setpoints are selectable per each input.

■ALARM TYPE (High or Low)

High or Low alarm is selectable for each alarm trip point. **High alarm**: An alarm is set when the input signal goes above the setpoint.

Low alarm: An alarm is set when the input signal goes below the setpoint.

■DEADBAND (HYSTERESIS)

(0.00 to 100.00 %; factory set to 5.00)

Deadband (deviation between the points where the alarm is set and reset) is selectable for each alarm trip point.

■ALARM ON DELAY TIME

(0.0 to 99.0 seconds; factory set to 1.0)

The alarm output is set when the preset time elapses after the input has entered in the alarm range.

This setting is common to all 8 points.

■POWER ON DELAY TIME

(0.0 to 99.0 seconds; factory set to 5.0)

The alarm output start functioning in the preset time after the power has been turned on.

This setting is common to all 8 points.


■ALARM HOLD TIME

(0.0 to 99.0 seconds; factory set to 1.0)

The alarm output is held for the preset time even if it is reset in shorter time.


This setting is common to all 8 points.

MODEL: R3-AV8




OUTPUT DATA DESCRIPTIONS

Four alarm setpoints are selectable per each input. Two (2) word (16 bits × 2) data is transmitterd to the PLC or the host device via the R3 network module.



EXTERNAL DIMENSIONS & TERMINAL ASSIGNMENTS unit: mm (inch)






幸託有限公司 **XIN TOP CORPORATION**

FAX: (02)2596-2331 Website: www.xintop.com

SCHEMATIC CIRCUITRY & CONNECTION DIAGRAM



*For dual redundant communication.

NOTE: Connect either wide or narrow span terminals for each channel.



Specifications are subject to change without notice.

幸託有限公司 **XIN TOP CORPORATION**

FAX: (02)2596-2331

Website: www.xintop.com