

## Single Loop Controller Series

### LOOP CONFIGURATION BUILDER

(for SC100/200 series use)

#### Functions & Features

- PC software controlling the function blocks of SC100/SC200 series and remote I/O devices.
- Running on Windows XP, Vista and 7.
- Visualized connecting information of I/O terminals with the graphical coding.
- Uploading to and downloading from SC100/SC200 series and remote I/O devices.
- Online monitoring.

Windows 7 Professional (32 bit, 64 bit)

Windows 7 Ultimate (32 bit, 64 bit)

**CPU:** 1 GHz or higher

**Memory:** 1 GB or greater

**Hard disk area:** Approx. 100 MB for installing

Note) Not guaranteed for all systems.

## MODEL: SFEW3E

Downloadable at M-System's web site.

### RELATED PRODUCTS

Provide the following accessories for the use with different devices.

DEVICES	ACCESORIES
SC100/SC200	IrDA Communication Adaptor (Model: COP-IRDA)
	PC Configurator Cable (Model: COP-US)
SML	PC Configurator Cable (Model: COP-UM)

### FUNCTIONS

- System configuration

Locates the devices on System Configuration View and configures NestBus system. The connection of communication terminals is configurable with graphical images.

- Function block setting

Function blocks are configurable for each device. The connection of I/O terminals is configurable with graphical images.

- Ladder setting

Ladder chart programming of the devices is available.

- PU-2 simulation

Simulates the Programming Unit (model: PU-2x).

- Online monitoring

The latest value of the devices can be monitored on display.

- Printing

Each view and function block setting list are printable.

### HARDWARE REQUIREMENTS (provided by the user)

#### Operating system:


Windows XP Professional (32 bit)

Windows Vista Business (32 bit)

Windows Vista Ultimate (32 bit)



**SYSTEM CONFIGURATION EXAMPLES**



Specifications are subject to change without notice.

