
## **Easy Use Instructions**

For Marathon Products Single-use Data Loggers.



## FOR SHIPPER:




01 Press the START button to begin recording.



04 Place logger in product to be shipped.



02 LED will blink 4 times to show activation. Once activated the Green LED will blink periodically.



05 Do not use logger if LEDs do not work.



**03** Place logger in waterproof bag



**06** Red ALARM LED will light if preset temperatures parameters are exceeded.





01 Read logger using MDAS Software and save Data.







幸託有限公司 TEL : (02)2598-1199 E-mail XIN TOP CORPORATION FAX : (02)2596-2331 Webs

9 E-mail : info@xintop.com 81 Website : www.xintop.com